



Below the ground base plates which stabilises the post during installation.

Prevents rotation, sinking into the ground and removal of post after concrete is set.

Sizes available:

- 50mm
- 76mm
- 89mm



Ground



Concrete

- 1) Place post on base plate and tighten bolt.
- 2) Place post into hole so post is level and straight.
- 3) Pour concrete around post.
- 4) Leave to set before attaching sign.

DRAWN		TITLE BASEPLATE	
CHECKED			
QA			
MFG			
APPROVED			
	SIZE	Drawing Number: A1	REV
	SCALE		
			SHEET 1 OF 20