


Wall Mounted

1. Attach backing plate to wall where sign is to be displayed.
2. Position front plate over backing plate and apply pressure to locate.
3. Insert media.
4. Insert clear cover.
5. Retain cover remover for removing clear cover when media needs changing. Repeat steps 3, 4 and 5.



Suspended

1. Fix the caps onto the extrusion with the screws supplied.
2. Clip the hanging rods through the holes on the end caps.
3. Fix the other end to the mounting area (ceiling etc).

