





STRYDER_{V2} **TROUGH LIGHT**

Wall Fitting Diagram

1. Mount the Brackets to the Wall in the desired position





2. Slot the sliders (mounted on the troughlight) over the wall bracket arms and bolt into place using the tooth washers & M6 Bolts





3. Slide the trough light into position, then tighten the Grub Screws in the Slider Bracket to clamp the trough light into place.








Tools Required




STRYDER_{V2} **TROUGH LIGHT** WITH JOINING CONNECTOR

Wall Fitting Diagram


1. Fixing the Brackets to the Wall in the desired position









3. Slide the Troughlight along the brackets and Female electrical connection onto the Male Connector.



4. Tighten the Grub Screws in the Slider Bracket to clamp the Troughlights into place.















STRYDER_{V2} **TROUGH LIGHT**

Channel Bracket Fitting Diagram

1. Fixing the Brackets to the Channel on the back of the panel in the desired position.





2. Slot the sliders (mounted on the troughlight) over the Channel bracket arms and bolt into place using the and external tooth washers / M6 Bolts





3.Tighten the Grub Screws in the Slider Bracket to clamp the Troughlights into place.











STRYDER_{V2} **TROUGHLIGHT**

Tray Top Bracket Fitting Diagram

1. Place the Tray Brackets to the Tray in the desired position, Drill holes then rivet or bolt into place.





2. Slot the sliders (mounted on the troughlight) over the tray bracket arms and bolt into place using the M6 Bolts





3.Tighten the Grub Screws in the Slider Bracket to clamp the Troughlights into place.

















STRYDER_{V2} **TROUGHLIGHT**

Plate Bracket Fitting Diagram

1. Place the Plate Brackets to the Plate in the desired position, Drill holes then rivet or bolt into place





2. Slot the sliders (mounted on the troughlight) over the plate bracket arms and bolt into place using the M6 Bolts





 ${\bf 3. Tighten\ the\ Grub\ Screws\ in\ the\ Slider\ Bracket\ to\ clamp\ the\ Troughlights\ into\ place.}$








Tools Required




STRYDER_{V2} **TROUGH LIGHT**


Double Sided Bracket Fitting Diagram













4.Slide the trough light into the correct position and then tighten the grub screws in the slider bracket to hold in place.










Optimum Light Chart

(Length of bracket from face of sign)
(if you are using a tray add the return depth to the bracket length)



Please note: These light measurements were taken using our Cool White LED (6000K) and may differ using Warm White LED (3000K)

Wall Bracket Length Example

